#### Step 5

Using a drill and a 5/32" bit, drill pilot holes in the wall being sure to stay centered on the stud. Be sure to check that all of the pilot holes line up with the bracket before proceeding. Make any necessary adjustments.

# Step 6

Again, have someone hold the seat in place while you set the screws in place. Use a #3 Phillips screwdriver to set the screws in part way. Double-check the level of the bench. This is your last chance to make any minor adjustments. Once you're satisfied with the level, using your power drill fitted with a #3 Phillips bit (you may need the 6" extension bit at this point), drive the screws firmly against the wall brackets. Do not over-tighten as this can compromise the strength of the bracket. Hand test all of the screws to be sure that they are solidly set in place.

# Step 7

Test the locking mechanism of the mounted bench, ensuring that the bench can be raised and lowered easily.

# Step 8

Load test the bench to confirm secure mounting.

# CAUTION:

You must adhere to your local building codes. If you are in doubt or feel unsure about mounting the bench yourself, contact a licensed contractor.

# TIPS:

If the brackets sound like they are grinding, simply loosen each screw very slightly (no more than a 1/4 turn at a time) while testing after each adjustment.

If you have any questions about the mounting procedure, feel free to contact Teakworks4u at 866.969.8325 or email customerservice@teakworks4u.com.

# Heavy Duty Wall-Mount Folding Bench Instructions TBF-22WHD, TBF-28WHD, TBF-36WHD, PTBF-22WHD, PTBF-28WHD & PTBF-36WHD



# Thank you for your order!

We are confident that you will enjoy your Wall-Mounted Teak Bench for many years to come. An essential part of your satisfaction is properly mounting the bench. Failure to do so may result in injury to you or a loved one.

If you are missing any of the hardware or any of the components appear to be damaged, please contact your dealer immediately. Do not attempt to mount the bench until any missing hardware or damage is corrected.

\*\*\*Must be mounted at least 18" above floor to fold properly\*\*\*

#### The tools you need are:

Stud Finder, Drill, 5/32" drill bit, #3 Phillips Screwdriver, 6" #3 Phillips Bit Extension, 12" or longer Level, Tape Measure, and a Pencil.

Before beginning, check your box. It should contain the bench with pre-attached mounting brackets and a hardware pack containing 6 #12x2-1/2" Marine Grade Stainless Steel Phillips head screws. Test the bench locking mechanisms to be sure that they operate properly. Pressing the tang at the front of bench will activate the mechanism.

### Step 1

Select the location for mounting the bench. Keep in mind that this bench is collapsible so be sure that there is enough clearance for proper operation. At least 18" above the floor.

# Step 2

Following the manufacturer's instructions for your electronic stud sensor, locate the wall studs. Depending on the type of stud sensor you have, you can also use it to locate any electrical wires or other obstructions in the wall. If you find

electrical wires, water pipes or any other obstructions, it is best to choose a different location for your bench.

**WARNING:** You must mount your bench directly into the center of your wall's wooden studs. **DO NOT** attempt to mount into steel studs or with any type of wall anchor. This will not provide adequate support.

# Step 3


Measure up from the floor to the desired height of the bench. We recommend a minimum of 18" to a maximum of 22" but you can vary this according to your specific requirements. Make a mark on the wall for the height. Using your level, mark a level horizontal line to reference as you continue.

**WARNING:** Be sure to include the thickness of the bench in your measurement calculations.

### Step 4

For easier mounting, the brackets on your bench are located at 16" on center, the same as most wall studs. Following the illustration below, mark the locations of the mounting holes for each bracket. You can also have someone hold the bench in position while you mark the holes directly from the bracket.

Continued on back Bracket Shown from Back Side



Side View

of Bracket

